



Note on Focal Point Dome:

The dome is to be painted and faux finished PRIOR to installation. After finishing, drill 3/16" holes through dome and insert fiber for